

HOT WORK PERMIT Permit # WARNING!

HOT WORK IN PROGRESS, WATCH FOR FIRE

This Hot Work Permit is required for any operation involving open flame or producing heat and/or sparks. This work includes, but is not limited to, welding, brazing, cutting, grinding, soldering, thawing pipe, torch-applied roofing, or chemical welding.

INSTRUCTIONS:

- <u>The person doing hot work</u>: Indicate time started and post this PERMIT at the work location. After hot work, indicate time completed and leave permit posted during final fire watch by UNO public safety.
- Fire Watch: The person doing the hot work <u>CANNOT</u> be the fire watch. Fire watch will continuously monitor during the hot work and one hour after the work is done. Before leaving the area, do a final inspection, sign the permit, leave the permit posted and notify the hot work authorizing supervisor about the completion of the work.
- Public Safety: Monitor work area every hour for the next 4 hours. Pick up the permit at the last inspection and return the permit to Dispatcher for the log entry.
- 4. <u>Public Safety Dispatcher:</u> If no call is received from the supervisor, call the permit-issuing supervisor for work status verification.

HOT WORK DONE BY		Date:			
0 0	UNO employee Contractor	Location: Room: Type of job:			
			Start time:	am	pm
NAME OF THE PERSON DOING THE HOT WORK			End time:	am	pm

I verify the above location has been examined, the precautions checked on the required checklist have been taken to prevent fire, and permission is authorized for this work.

AUTHORIZING UNO SUPERVISOR'S NAME

SIGNATURE

FIRE WATCH SIGNOFF

I certify that 60 minutes after completion of any Hot Work operations, the work area and all adjacent areas to which sparks and heat might have spread (including floors above and below and on the opposite side of the walls) were inspected and found to be safe

FIRE WATCH'S NAME

FIRE WATCH'S SIGNATURE

REQUIRED PRECAUTIONS CHECKLIST

- Available sprinklers and extinguishers are in service and operable.
- Hot Work equipment in good repair.

REQUIREMENTS WITHIN 35 FT. (11M) OF WORK

- Flammable liquids, dust, lint, and oily deposits were removed.
- The explosive atmosphere in the area was eliminated.
- Floors swept clean.
- Combustible Floors wet down or covered with fire-resistant material.
- Remove other combustibles where possible, otherwise protect with fire-resistant material.
- All wall and floor openings are covered.
- Fire-resistant tarpaulins suspended beneath work.

WORK ON LC WALLS OR CEILING

- Construction is noncombustible and without combustible covering or insulation.
- Combustibles on the other side of walls moved away

WORK ON ENCLOSED EQUIPMENT

- Enclosed equipment is cleaned of all combustibles.
- Containers were purged and cleaned.
- Pressurized vessels, piping, and equipment were removed from service, isolated, and vented.

FIRE WATCH/HOT WORK AREA MONITORING

- Fire Watch will be provided during and for 60 minutes after work including any coffee or lunch breaks.
- Fire Watch is supplied with suitable extinguishers.
- Fire Watch is trained in the use of this equipment and sounding the alarm.
- Fire Watch may be required for adjoining areas, above, and below.
- Public Safety checks the Hot Work area for 4 hours after the job is completed

OTHER PRECAUTIONS TAKEN:

The work area was checked every hour for 4 hours following Hot Work and found safe.

OFFICER'S SERIAL NUMBER

TIME

TIME

OFFICER'S SERIAL NUMBER

OFFICER'S SERIAL NUMBER

TIME

WARNING! HOT WORK IN PROGRESS



In case of emergency call Public Safety at

402-554-2911